


## 5. SRAM/Clock Adjustment


Pressing the [SRAM/Clock] switch in the Main Menu drop-down window displays the SRAM/Clock Adjustment screen.

This screen allows users to adjust the date and time and format the SRAM area.

[Main Menu]



SRAM/Clock Adjustment screen



A "Battery changeover required" alert message is displayed here <sup>\*1</sup>.


\*1 Always replace the battery when required. The clock setting and contents of the SRAM area cannot be retained without a power supply.

## 5-1. Date and Time Adjustment

This screen can be used to adjust the built-in clock of the TS2060 unit.

Set whether to use the built-in clock in the TS2060 unit or the clock in a PLC by selecting [System Setting] → [Unit Setting] → [SRAM/Clock] → [SRAM/Clock Setting] → [Use Built-in Clock] on V-SFT-6.

1. Use the [←] and [→] switches to move the cursor and [+] and [-] switches to adjust the date and time.
2. After adjustment, press the [Set] switch to confirm the setting. The clock displayed at the top right is updated.




3. Press the [Return] switch to return to the Main Menu screen.

## 5-2. Formatting SRAM

An SRAM area can be formatted.

When the SRAM area is formatted, any saved data (history data saved in SRAM, internal device memory \$L, etc.) is completely cleared. Exercise caution when formatting the SRAM area.

1. Press the [Format] switch and then the [Execute] switch.  
The SRAM area is formatted in the format specified in the current screen program. When formatting is complete, the message "\*\*\*Format Completed\*\*" is displayed.



2. Press the [Return] switch to return to the Main Menu screen.