

7. Storage Transfer

Pressing the [Storage Transfer] switch in the Main Menu drop-down window displays the Storage Transfer screen.


This screen is used to transfer screen programs between a TS2060i unit and storage device (SD card or USB flash drive) * or between a TS2060 unit and memory card.

* Transfer using a storage device is only supported on the TS2060i unit.

[Main Menu]




Storage Transfer screen




When [Display → Storage] Is Selected

- When [Display → Storage] is selected, the Storage Transfer screen appears.



- Check the storage file information and folder name and then press the [Start] switch.
 - * If the access folder of the screen program and that on the SD card are named the same, the data on the SD card will be overwritten.
 - If the [Storage File Information] field is blank, a new file called "DSP0000.BIN" will be created in the DSP folder under the access folder.
- During the transfer, the [Start] switch changes to read [Transferring]. On successful completion, the following window is displayed. Press the [OK] switch.



The storage file information changes to information on the transferred data.

- * If any other error message is displayed, refer to "Errors Displayed during Data Transfer (between a TS2060i Unit and Storage Device)" page 5-29.